

お客様へ



安心してお使いいただくために操作方法を説明するラベルです。  
見やすい位置に貼ってご使用ください。

メーカー管理用です。



## 使いかた Operations 使用方法 사용방법

これはおしりを洗うことができる便座です。

This is a toilet seat with a water-cleansing function for your rear.

本便座可以清洗臀部。

이 제품은 전기식 비데입니다.

便座に座ると、各機能が使えます。

When sitting on the toilet seat, the seat switch turns ON, enabling various features.

坐上便座后,可使用各种功能。

시트에 앉으면 각 기능을 사용할 수 있습니다.

More Information



止める Stopping 停止 정지	洗う Washing 清洗 세정	かわかす Drying 干燥 건조	
洗浄を止めます。 Stops the operation. 停止清洗。 세정을 정지합니다.	おしりを洗います。 Cleanses your rear. 清洗臀部。 세정을 합니다.	ビデ洗浄します。 Cleanses your front (for ladies). 清洗女性下身。 비데 세정을 합니다.	おしりをかわかします。 Dries wet areas. 烘干臀部。 건조시킵니다.

  

水勢を調節する Water pressure adjustment 调节水势 수압을 조절	洗浄位置を調節する Water position adjustment 调节清洗位置 세정 위치를 조절
水勢を5段階で調節します。 Select the water pressure from 5 levels. 可分5档调节水势。 수압을 5단계로 조절할 수 있습니다.	洗浄位置を5段階で調節します。 Select the wand position from 5 levels. 可分5档调节清洗位置。 세정 위치를 5단계로 조절할 수 있습니다.

The diagram shows a control panel with four main buttons: STOP, REAR (with a rear icon), FRONT (with a front icon), and DRYER (with a drying icon). Below these are two sliders: '水勢 PRESSURE' with minus and plus buttons, and '位置 POSITION' with up and down arrow buttons. The TOTO logo is at the bottom center.

D00801 ㉨